

STEP 1



TIP SHEET

Safe and simple ink color changes

# Color Change™ On Press Ink Remover



Quickly change colors on press or open clogged mesh areas during a run, saving valuable time and money. Franmar's **Color Change™ On Press Ink Remover** is non-aerosol and replaces harsh chemicals like methylene chloride without hazardous side effects and noxious odors.

## Color Changing Directions:

1. Spray or pour a small amount onto screen.
2. Wipe screen clean.
3. Repeat on back of screen image.
4. Allow to dry thoroughly.

## Screen Opener Directions:

1. Spray or pour a small amount onto applicator.
2. Wipe screen image area clean.

## Usage Tips:

- Remember, less is more. Use a small amount and you will immediately see the ink loosen.
- Works great for cleaning ink smudges on back of screen.
- Franmar's **D•GREASE™** can be used to wipe away any solvent residues.
- Start with lighter inks and move up to darker inks when printing.

## MORE INFORMATION:

**Precautions:** Dispose of waste according to local regulations. Avoid eye contact. If product contacts eye, rinse thoroughly with water. Call a physician if irritation persists. If swallowed do not induce vomiting. Call a physician. Nitrile or neoprene gloves are recommended for sensitive skin.



Chat with a live customer service rep:

**800-538-5069**

8:00am - 5:00pm CST Monday - Friday  
or visit our website: [www.franmar.com](http://www.franmar.com)

rev. 3/30/2023