



TIP SHEET

Saves 100% white cotton apparel

Scorch•e•doo™

Scorch Remover



Scorch marks left by flash curing units and dryers have always been an occasional problem for screen printers. Franmar's **Scorch•e•doo™ Scorch Remover** is a great product to have on hand for those moments shirts get scorched with no extras in sight. An eco-friendly choice to recover burned white cotton shirts.

Directions:

1. Spray on affected area until damp.
2. Place in dryer at reduced heat or higher belt speed multiple times until dry. A warm iron or heat press may also be used.
3. Repeat process if necessary.

Usage Tips:

- Use only on light scorches. Will not work on medium to severe scorches.
- Use only on white cotton apparel. Will not work on polyester blends.
- A heat press at a low temp (~225°F / 107.2°C) works well after applying **Scorch•e•doo**.

MORE INFORMATION:

Precautions: Dispose of waste according to local regulations. Avoid eye contact. If product contacts eye, rinse thoroughly with water. Call a physician if irritation persists. If swallowed do not induce vomiting. Call a physician. Nitrile or neoprene gloves are recommended for sensitive skin.



Chat with a live customer service rep:

800-538-5069

8:00am - 5:00pm CST Monday - Friday
or visit our website: www.franmar.com

rev. 3/30/2023